

Refill Instructions - Lexmark 10N0016 (No.16)

Order your

Refill PACKs at:

www.refill4.com



fig.2

LexmarkAll in One X72 . X74 . X75 . X1130 . X1150 . X1180 . X225
Color Jetprinter Z13 . Z23 . Z25 . Z33 . Z34 . Z35 . Z515 . Z601 . Z605 . Z615

Items Required

Original Lexmark 16 Cartridge, Syringe & Filling Tube
Black Ink 10ml

Instructions

1. Assemble syringe and steel filling tube and fill with appropriate colour ink (g.2)
2. Remove the top from the black ink bottle and use the syringe remove 10ml of black ink (g.3)
3. The filler hole is located on top of the cartridge. (g.4)

4. Insert the steel filling tube into the appropriate fill holes. (g.5). Push down into centre of the sponge.
IMPORTANT: Cartridge contains a sponge and a slight resistant may be felt.

5. **SLOWLY** Inject ink. When ink overflows from filling hole or starts to leak from print heads cartridge is full. Stop injecting immediately

Blot printer heads with tissue before continuing to next colour

IMPORTANT: Clean syringe with water and dry before refilling next colour

6. After refilling replace label back over filling hole.
7. Leave the cartridge to stand overnight on non-absorbent surface this will ensure no leakage and give the ink time to fully saturate the sponge.

IMPORTANT: DO NOT LEAVE ON TISSUE.

8. Install cartridge and run a priming cycle.

PLEASE NOTE: The ink indicator level may need to be turned off. Check your HP instructions manual for details.




fig.3

Black




fig.4

Refilling
Hole




fig.5